



# HIMax<sup>®</sup>

Digital Output Module  
Manual

SAFETY  
NONSTOP



# X-DO 32 51

---

All HIMA products mentioned in this manual are protected by the HIMA trade-mark. Unless noted otherwise, this also applies to other manufacturers and their respective products referred to herein.

All of the instructions and technical specifications in this manual have been written with great care and effective quality assurance measures have been implemented to ensure their validity. For questions, please contact HIMA directly. HIMA appreciates any suggestion on which information should be included in the manual.

Equipment subject to change without notice. HIMA also reserves the right to modify the written material without prior notice.

For further information, refer to the HIMA DVD and our website at <http://www.hima.de> and <http://www.hima.com>.

© Copyright 2012, HIMA Paul Hildebrandt GmbH + Co KG

All rights reserved

## Contact

HIMA contact details:

HIMA Paul Hildebrandt GmbH + Co KG

P.O. Box 1261

68777 Brühl, Germany

Phone: +49 6202 709-0

Fax: +49 6202 709-107

E-mail: [info@hima.com](mailto:info@hima.com)

Revision index	Revisions	Type of change	
		technical	editorial
4.00	First Edition of the SILworX V4 Manual		
4.01	Revised: Chapter 3.2 and 3.5	X	X
4.02	Deleted: Redundant connector boards	X	X

## Table of Contents

<b>1</b>	<b>Introduction</b>	<b>5</b>
1.1	Structure and Use of this Manual	5
1.2	Target Audience	5
1.3	Formatting Conventions	6
1.3.1	Safety Notes	6
1.3.2	Operating Tips	7
<b>2</b>	<b>Safety</b>	<b>8</b>
2.1	Intended Use	8
2.1.1	Environmental Requirements	8
2.1.2	ESD Protective Measures	8
2.2	Residual Risk	9
2.3	Safety Precautions	9
<b>3</b>	<b>Product Description</b>	<b>10</b>
3.1	Safety Function	10
3.1.1	Reaction in the Event of a Fault	10
3.2	Scope of Delivery	10
3.3	Type Label	11
3.4	Structure	12
3.4.1	Block Diagram	13
3.4.2	Indicators	14
3.4.3	Module Status Indicators	15
3.4.4	System Bus Indicators	16
3.4.5	I/O Indicators	16
3.5	Product Data	17
3.6	Connector Boards	19
3.6.1	Mechanical Coding of X-CB 009 5X Connector Boards	19
3.6.2	Coding of X-CB 009 5X Connector Boards	20
3.6.3	Connector Board with Screw Terminals	21
3.6.4	Terminal Assignment for Connector Boards with Screw Terminals	22
3.6.5	Connector Board with Cable Plug	24
3.6.6	Pin Assignment for Connector Boards with Cable Plug	25
3.7	System Cable X-CA 006	26
3.7.1	Cable Plug Coding	27

<b>4</b>	<b>Start-up</b>	<b>28</b>
<b>4.1</b>	<b>Mounting</b>	<b>28</b>
4.1.1	Wiring Outputs not in Use	28
<b>4.2</b>	<b>Mounting and Removing the Module</b>	<b>29</b>
4.2.1	Mounting a Connector Board	29
4.2.2	Mounting and Removing the Module	31
<b>4.3</b>	<b>Configuring the Module in SILworX</b>	<b>33</b>
4.3.1	Tab: Module	34
4.3.2	Tab: I/O Submodule DO32_51	35
4.3.3	Tab: I/O Submodule DO32_51: Channels	36
4.3.4	Submodule Status [DWORD]	36
4.3.5	Diagnostic-Status [DWORD]	37
<b>4.4</b>	<b>Connection Variants</b>	<b>38</b>
4.4.1	1-Pole Wiring of Actuators	38
4.4.2	2-Pole Wiring of Actuators	38
4.4.3	Wiring Actuators to Redundant Modules	39
4.4.4	Wiring Inductive Loads	39
4.4.5	Wiring Actuators via Field Termination Assembly	40
<b>5</b>	<b>Operation</b>	<b>41</b>
<b>5.1</b>	<b>Handling</b>	<b>41</b>
<b>5.2</b>	<b>Diagnosis</b>	<b>41</b>
<b>6</b>	<b>Maintenance</b>	<b>42</b>
<b>6.1</b>	<b>Maintenance Measures</b>	<b>42</b>
6.1.1	Loading the Operating System	42
<b>7</b>	<b>Decommissioning</b>	<b>43</b>
<b>8</b>	<b>Transport</b>	<b>44</b>
<b>9</b>	<b>Disposal</b>	<b>45</b>
	<b>Appendix</b>	<b>46</b>
	Glossary	46
	Index of Figures	47
	Index of Tables	48
	Index	49

# 1 Introduction

The present manual describes the technical characteristics of the module and its use. It provides information on how to install, start up and configure the module in SILworX.

## 1.1 Structure and Use of this Manual

The content of this manual is part of the hardware description of the HIMax programmable electronic system.

This manual is organized in the following main chapters:

- Introduction
- Safety
- Product Description
- Start-up
- Operation
- Maintenance
- Decommissioning
- Transport
- Disposal

Additionally, the following documents must be taken into account:

Name	Content	Document no.
HIMax System manual	Hardware description of the HIMax system	HI 801 001 E
HIMax Safety manual	Safety functions of the HIMax system	HI 801 003 E
HIMax Communication manual	Description of communication and protocols	HI 801 101 E
SILworX Online Help (OLH)	Instructions on how to use SILworX	-
First Steps	Introduction to SILworX	HI 801 103 E

Table 1: Additional Relevant Manuals

The latest manuals can be downloaded from the HIMA website at [www.hima.com](http://www.hima.com). The revision index on the footer can be used to compare the current version of existing manuals with the Internet edition.

## 1.2 Target Audience

This document addresses system planners, configuration engineers, programmers of automation devices and personnel authorized to implement, operate and maintain the devices and systems.

### 1.3 Formatting Conventions

To ensure improved readability and comprehensibility, the following fonts are used in this document:

<b>Bold:</b>	To highlight important parts Names of buttons, menu functions and tabs that can be clicked and used in SILworX.
<i>Italics:</i>	System parameter and variables
Courier	Literal user inputs
RUN	Operating state are designated by capitals
Chapter 1.2.3	Cross references are hyperlinks even though they are not particularly marked. When the cursor hovers over a hyperlink, it changes its shape. Click the hyperlink to jump to the corresponding position.

Safety notes and operating tips are particularly marked.

#### 1.3.1 Safety Notes

The safety notes are represented as described below. These notes must absolutely be observed to reduce the risk to a minimum. The content is structured as follows:

- Signal word: danger, warning, caution, notice
- Type and source of danger
- Consequences arising from the danger
- Danger prevention

#### SIGNAL WORD



**Type and source of danger!**  
**Consequences arising from the danger**  
**Danger prevention**

---

The signal words have the following meanings:

- Danger indicates hazardous situation which, if not avoided, will result in death or serious injury.
- Warning indicates hazardous situation which, if not avoided, could result in death or serious injury.
- Caution indicates hazardous situation which, if not avoided, could result in minor or modest injury.
- Notice indicates a hazardous situation which, if not avoided, could result in property damage.

#### NOTICE



**Type and source of damage!**  
**Damage prevention**

---

### 1.3.2 Operating Tips

Additional information is structured as presented in the following example:

---

**i**

The text corresponding to the additional information is located here.

---

Useful tips and tricks appear as follows:

---

**TIP**

The tip text is located here.

---

## 2 Safety

All safety information, notes and instructions specified in this manual must be strictly observed. The product may only be used if all guidelines and safety instructions are adhered to.

This product is operated in accordance with SELV or PELV. No imminent danger results from the module itself. The use in Ex-Zone is permitted if additional measures are taken.

### 2.1 Intended Use

HIMax components are designed for assembling controller systems.

When using the components in the HIMax system, comply with the following general requirements

#### 2.1.1 Environmental Requirements

Requirement type	Range of values
Protection class	Protection class III in accordance with IEC/EN 61131-2
Ambient temperature	0...+60 °C
Storage temperature	-40...+85 °C
Pollution	Pollution degree II in accordance with IEC/EN 61131-2
Altitude	< 2000 m
Housing	Standard: IP20
Supply voltage	24 VDC

Table 2: Environmental Requirements

Exposing the HIMax system to environmental conditions other than those specified in this manual can cause the HIMax system to malfunction.

#### 2.1.2 ESD Protective Measures

Only personnel with knowledge of ESD protective measures may modify or extend the system or replace modules.

#### NOTE



##### Device damage due to electrostatic discharge!

- When performing the work, make sure that the working area is free of static and wear an ESD wrist strap.
- If not used, ensure that the device is protected from electrostatic discharge, e.g., by storing it in its packaging.

## 2.2 Residual Risk

No imminent danger results from a HIMax module itself.

Residual risk may result from:

- Faults in the engineering
- Faults in the user program
- Faults in the wiring

## 2.3 Safety Precautions

Observe all local safety requirements and use the protective equipment required on site.

## 3 Product Description

X-DO 32 51 is a digital NonSIL output module intended for use in the programmable electronic system (PES) HIMax.

The module can be inserted into any of the base plate slots with the exception of the slots reserved for system bus modules. For more information, see System Manual (HI 801 001 E).

The module is equipped with 32 digital outputs that can be loaded with a nominal current of up to 0.5 A per channel. At high level, a voltage equivalent to the supply voltage is present on the corresponding output.

The outputs are suitable for connecting ohmic, inductive and capacitive loads and lamps.

It can be operated with safety-related modules and other NonSIL modules within one base plate. Safety-related and NonSIL modules may not be wired redundantly.

The module is interference-free, in particular, with respect to EMC, electrical safety, communication to the X-SB and X-CPU modules, as well as the user program.

Module and connector boards are mechanically coded, see Chapter 3.6.1. Coding avoids installation of improper modules.

Refer to the HIMax Safety Manual (HI 801 003 E) for more information on the standards used to test and certify the modules and the HIMax system.

### 3.1 Safety Function

The module does not perform any safety-related functions.

Each switch of a channel can be individually switched off via the system bus (I/O bus).

The parameters and status for this module must not be used for safety functions.

#### 3.1.1 Reaction in the Event of a Fault

If a channel fault occurs, the affected channel is switched off. If a module fault occurs, all outputs are switched off.

If the system bus fails, the outputs are de-energized.

The module activates the *Error* LED on the front plate.

### 3.2 Scope of Delivery

The module must be installed on a suitable connector board to be able to operate. If a Field Termination Assembly (FTA) is used, a system cable is required to connect the connector board to the FTA. Connector boards, system cables and FTAs are not included within the scope of delivery.

The connector boards are described in Chapter 3.6, the system cables are described in Chapter 3.7. The FTAs are described in own manuals.

### 3.3 Type Label

The type label specifies the following important details:

- Product name
- Mark of conformity
- Bar code (2D or 1D code)
- Part number (Part-No.)
- Hardware revision index (HW Rev.)
- Software revision index (SW Rev.)
- Operating voltage (Power)
- Ex specifications (if applicable)
- Production year (Prod-Year:)



Figure 1: Sample Type Label

### 3.4 Structure

The module is equipped with 32 digital outputs. The outputs are not electrically isolated from one another and from the voltage supply.

The module is equipped with a current limiting function, which limits the total current of all the 32 outputs. Additionally, the module monitors the total current for overload. If an overload is present for longer than 100 ms, all the outputs are switched off and switched on again after ten seconds. If the overload is still present, all the outputs are switched off again for ten seconds. This process is repeated as long as the overload is present.


If an output overload is detected, the corresponding channel is switched off and automatically switched on again after five seconds as soon as the overload is no longer present.

The processor system for the I/O module controls and monitors the I/O level. The data and states of the I/O module are made available to the processor modules via the redundant system bus. The system bus has a redundant structure for reasons of availability. Redundancy is only ensured if both system bus modules are inserted in the base plates and configured in SILworX.

The module is equipped with LEDs to indicate the status of the digital outputs, see Chapter 3.4.2.

### 3.4.1 Block Diagram

The following block diagram illustrates the structure of the module.



- 1** System Busses
- 2** Processor System
- 3** Interface
- 4** Current Limiting

Figure 2: Block Diagram

### 3.4.2 Indicators

The following figure shows the LED indicators for the module.




Figure 3: Indicators

The LEDs indicate the operating state of the module.

The LEDs on the module are divided into three groups:

- Module status indicators (Run, Error, Stop, Init)
- System bus indicators (A, B)
- I/O indicators (DO 1...32, Field)

When the supply voltage is switched on, a LED test is performed and all LEDs briefly flash simultaneously.

**Definition of Blinking Frequencies**

The following table defines the blinking frequencies of the LEDs:

Name	Blinking Frequencies
Blinking1	Long (approx. 600 ms) on, long (approx. 600 ms) off
Blinking2	Short (approx. 200 ms) on, short (approx. 200 ms) off, short (approx. 200 ms) on, long (approx. 600 ms) off
Blinking-x	Ethernet communication: Flashing in sync with data transfer

Table 3: Blinking Frequencies of LEDs

3.4.3 Module Status Indicators

These LEDs are located on the front plate, on the upper part of the module.

LED	Color	Status	Description
Run	Green	On	Module in RUN, normal operation
		Blinking1	Module state: STOP/OS_DOWNLOAD or OPERATE (only with processor modules)
		Off	Module not in RUN, observe the other status LEDs
Error	Red	On/Blinking1	Internal module faults detected by self-tests, e.g., hardware, software or voltage supply. Fault while loading the operating system
		Off	Normal operation
Stop	Yellow	On	Module state: STOP / VALID CONFIGURATION
		Blinking1	Module state: STOP / INVALID CONFIGURATION or STOP / OS_DOWNLOAD
		Off	Module not in STOP, observe the other status LEDs
Init	Yellow	On	Module state: INIT, observe the other status LEDs
		Blinking1	Module state: LOCKED, observe to the other status LEDs
		Off	Module state: neither INIT nor LOCKED, observe the other status LEDs

Table 4: Module Status Indicators

### 3.4.4 System Bus Indicators

The system bus LEDs are labeled *Sys Bus*.

LED	Color	Status	Description
A	Green	On	Physical and logical connection to the system bus module in slot 1.
		Blinking1	No physical connection to the system bus module in slot 1.
	Yellow	Blinking1	The physical connection to the system bus module in slot 1 has been established. No connection to a (redundant) processor module running in system operation.
B	Green	On	Physical and logical connection to the system bus module in slot 2.
		Blinking1	No physical connection to the system bus module in slot 2.
	Yellow	Blinking1	The physical connection to the system bus module in slot 2 has been established. No connection to a (redundant) processor module running in system operation.
A+B	Off	Off	Neither physical nor logical connection to the system bus modules in slot 1 and slot 2.

Table 5: System Bus Indicators

### 3.4.5 I/O Indicators

The LEDs of the I/O indicators are labeled *Channel*.

LED	Color	Status	Description
Channel 1...32	Yellow	On	The related channel is active (energized).
		Blinking2	Channel fault
		Off	The related channel is inactive (de-energized).
Field	Red	Blinking2	Field faults in at least one channel (e.g., overload)
		Off	No field fault displayed!

Table 6: I/O Indicators LEDs

### 3.5 Product Data

General	
Supply voltage	24 VDC, -15...+20 %, $r_p \leq 5$ %, SELV, PELV
Current input	min. 0.27 A (idle) max. 12.5 A
Operating temperature	0...+60 °C
Storage temperature	-40...+85 °C
Humidity	max. 95 % relative humidity, non-condensing
Type of protection	IP20
Dimensions (H x W x D) in mm	310 x 29.2 x 230
Weight	approx. 0.95 kg

Table 7: Product Data




Figure 4: Views

Digital outputs	
Number of outputs (number of channels)	32, non-galvanically isolated
Output voltage	$\geq L+$ minus internal voltage drop
Voltage drop (at high level)	1.8 V at 0.75 A output current
Nominal rated current (at high level)	0.5 A, range 0...0.6 A
Permissible total output current	12 A
Current limiting for total output current	16 A
Leakage current (at low level)	5 $\mu$ A
Max. output current for each channel	1.7 A
Ohmic load	To nom. rated current 0.5 A
Inductive load	15 H
Capacitive load	100 $\mu$ F
Lamp load (24 V)	4 W
Overload protection of the outputs, transient	33 V (max. 43 V)
Switching time of the channels (with ohmic load)	$\leq 100 \mu$ s
Behavior upon overload of individual outputs	The affected output is switched off
Behavior upon overload of the total output current	All outputs are switched off and cyclically switched on again

Table 8: Specifications for the Digital Outputs

### 3.6 Connector Boards

A connector board connects the module to the field zone. Module and connector board form together a functional unit. Insert the connector board into the appropriate slot prior to mounting the module.

The following connector boards are available for the module:

Designation	Description
X-CB 009 51	Mono connector board with screw terminals
X-CB 009 53	Mono connector board with cable plug

Table 9: Available Connector Boards

#### 3.6.1 Mechanical Coding of X-CB 009 5X Connector Boards

I/O modules and connector boards are mechanically coded starting from hardware revision AS00 to prevent them from being equipped with improper I/O modules. Coding avoids installation of improper I/O modules thus preventing negative effects on redundant modules and field zone. A part from that, improper equipment has no effect on the HIMax system since only I/O modules that are correctly configured in SILworX enter the RUN state.

I/O modules and the corresponding connector boards have a mechanical coding in form of wedges. The coding wedges in the female connector of the connector board match with the male connector recesses of the I/O module plug, see Figure 5.

Coded I/O modules can only be plugged in to the corresponding connector boards.




Figure 5: Coding Example

Coded I/O modules can be plugged in to uncoded connector boards. Uncoded I/O modules cannot be plugged in to coded connector boards.

### 3.6.2 Coding of X-CB 009 5X Connector Boards


a7	a13	a20	a26	c7	c13	c20	c26
X	X	X				X	

Table 10: Position of Coding Wedges

### 3.6.3 Connector Board with Screw Terminals

**Mono**

X-CB 009 51



**1** I/O Module Plug

**2** Connection to the Field Zone (Screw Terminals)

Figure 6: Connector Board with Screw Terminals

## 3.6.4 Terminal Assignment for Connector Boards with Screw Terminals

Pin no.	Designation	Signal	Pin no.	Designation	Signal
1	01a	DO1+	1	02a	DO2+
2	01b	DO1-	2	02b	DO2-
3	03a	DO3+	3	04a	DO4+
4	03b	DO3-	4	04b	DO4-
5	05a	DO5+	5	06a	DO6+
6	05b	DO5-	6	06b	DO6-
7	07a	DO7+	7	08a	DO8+
8	07b	DO7-	8	08b	DO8-
Pin no.	Designation	Signal	Pin no.	Designation	Signal
1	09a	DO9+	1	10a	DO10+
2	09b	DO9-	2	10b	DO10-
3	11a	DO11+	3	12a	DO12+
4	11b	DO11-	4	12b	DO12-
5	13a	DO13+	5	14a	DO14+
6	13b	DO13-	6	14b	DO14-
7	15a	DO15+	7	16a	DO16+
8	15b	DO15-	8	16b	DO16-
Pin no.	Designation	Signal	Pin no.	Designation	Signal
1	17a	DO17+	1	18a	DO18+
2	17b	DO17-	2	18b	DO18-
3	19a	DO19+	3	20a	DO20+
4	19b	DO19-	4	20b	DO20-
5	21a	DO21+	5	22a	DO22+
6	21b	DO21-	6	22b	DO22-
7	23a	DO23+	7	24a	DO24+
8	23b	DO23-	8	24b	DO24-
Pin no.	Designation	Signal	Pin no.	Designation	Signal
1	25a	DO25+	1	26a	DO26+
2	25b	DO25-	2	26b	DO26-
3	27a	DO27+	3	28a	DO28+
4	27b	DO27-	4	28b	DO28-
5	29a	DO29+	5	30a	DO30+
6	29b	DO29-	6	30b	DO30-
7	31a	DO31+	7	32a	DO32+
8	31b	DO31-	8	32b	DO32-

Table 11: Terminal Assignment for Connector Boards with Screw Terminals

Cable plugs attached to the connector board pin headers are used to connect to the field zone.

The cable plugs feature the following properties:


Connection to the field zone	
Cable plugs	8 pieces, with 8 poles
Wire cross-section	0.2...1.5 mm <sup>2</sup> (single-wire) 0.2...1.5 mm <sup>2</sup> (finely stranded) 0.2...1.5 mm <sup>2</sup> (with wire end ferrule)
Stripping length	6 mm
Screwdriver	Slotted 0.4 x 2.5 mm
Tightening torque	0.2...0.25 Nm

Table 12: Cable Plug Properties

### 3.6.5 Connector Board with Cable Plug

**Mono**

X-CB 009 53



**1** I/O Module Plug

**2** Connection to the Field Zone (Cable Plug in Row 1)

**3** Connection to the Field Zone (Cable Plug in Row 32)

**4** Coding for Cable Plugs

Figure 7: Connector Board with Cable Plug

### 3.6.6 Pin Assignment for Connector Boards with Cable Plug

HIMA provides ready-made system cables for use with this connector board, see Chapter 3.7. The cable plug and the connector boards are coded.

#### i

#### Connector pin assignment!

The following table describes the connector pin assignment of the system cable plug.

Lead marking based on DIN 47100:

Row	c		b		a	
	Signal	Color	Signal	Color	Signal	Color
1	DO32+	PK-BN <sup>1)</sup>	DO32-	WH-PK <sup>1)</sup>	Reserved	BN-RD <sup>2)</sup>
2	DO31+	GY-BN <sup>1)</sup>	DO31-	WH-GY <sup>1)</sup>	Reserved	WH-RD <sup>2)</sup>
3	DO30+	YE-BN <sup>1)</sup>	DO30-	WH-YE <sup>1)</sup>	Reserved	BN-BU <sup>2)</sup>
4	DO29+	BN-GN <sup>1)</sup>	DO29-	WH-GN <sup>1)</sup>	Reserved	WH-BU <sup>2)</sup>
5	DO28+	RD-BU <sup>1)</sup>	DO28-	GY-PK <sup>1)</sup>		
6	DO27+	VT <sup>1)</sup>	DO27-	BK <sup>1)</sup>		
7	DO26+	RD <sup>1)</sup>	DO26-	BU <sup>1)</sup>		
8	DO25+	PK <sup>1)</sup>	DO25-	GY <sup>1)</sup>		
9	DO24+	YE <sup>1)</sup>	DO24-	GN <sup>1)</sup>		
10	DO23+	BN <sup>1)</sup>	DO23-	WH <sup>1)</sup>		
11	DO22+	RD-BK	DO22-	BU-BK		
12	DO21+	PK-BK	DO21-	GY-BK		
13	DO20+	PK-RD	DO20-	GY-RD		
14	DO19+	PK-BU	DO19-	GY-BU		
15	DO18+	YE-BK	DO18-	GN-BK		
16	DO17+	YE-RD	DO17-	GN-RD		
17	DO16+	YE-BU	DO16-	GN-BU		
18	DO15+	YE-PK	DO15-	PK-GN		
19	DO14+	YE-GY	DO14-	GY-GN		
20	DO13+	BN-BK	DO13-	WH-BK		
21	DO12+	BN-RD	DO12-	WH-RD		
22	DO11+	BN-BU	DO11-	WH-BU		
23	DO10+	PK-BN	DO10-	WH-PK		
24	DO9+	GY-BN	DO9-	WH-GY		
25	DO8+	YE-BN	DO8-	WH-YE		
26	DO7+	BN-GN	DO7-	WH-GN		
27	DO6+	RD-BU	DO6-	GY-PK		
28	DO5+	VT	DO5-	BK		
29	DO4+	RD	DO4-	BU		
30	DO3+	PK	DO3-	GY		
31	DO2+	YE	DO2-	GN		
32	DO1+	BN	DO1-	WH		

<sup>1)</sup> Additional orange ring if one lead marking color is repeated.  
<sup>2)</sup> Additional violet ring if one lead marking color is repeated for the second time.


Table 13: Pin Assignment for the System Cable Plug

### 3.7 System Cable X-CA 006

The X-CA 006 system cable is used to connect the X-CB 009 53 connector board to the field termination assemblies.

General	
Cable	LIYY 64 x 0.34 mm <sup>2</sup> + 2 x 2 x 0.25 mm <sup>2</sup>
Wire	Finely stranded
Average outer diameter (d)	approx. 17.2 mm
Minimum bending radius	
Fixed laying	5 x d
Flexible application	10 x d
Combustion behavior	Flame resistant and self-extinguishing in accordance with IEC 60332-1-2, -2-2
Length	8...30 m
Color coding	Based on DIN 47100, see Table 13.

Table 14: Cable Data



**1** Identical Cable Plugs

Figure 8: X-CA 006 01 n

The system cable is available in the following standard length:

System cable	Description	Length
X-CA 006 01 8	Coded cable plugs on both sides	8 m
X-CA 006 01 15		15 m
X-CA 006 01 30		30 m

Table 15: Available System Cables

### 3.7.1 Cable Plug Coding

The cable plugs are equipped with three coding pins. Therefore, cable plugs only match connector boards and FTAs encoded accordingly, see Figure 7.

## 4 Start-up

This chapter describes how to install, configure and connect the module. For more information, refer to HIMax System Manual (HI 801 001 E).

### 4.1 Mounting

Observe the following points when mounting the module:

- Only operate the module with the appropriate fan components. For more information, see the System Manual (HI 801 001 E).
- Only operate the module with the suitable connector board. For more information, see Chapter 3.6.
- The module and its connected components must be mounted to provide protection of at least IP20 in accordance with EN 60529: 1991 + A1: 2000.

#### NOTE



**Damage due to incorrect wiring!**

**Failure to comply with these instructions can damage the electronic components.**

**Observe the following points!**

- Plugs and terminals connected to the field zone.
  - Take the appropriate earthing measures when connecting the plugs and terminals to the field zone.
  - An unshielded, twisted pair cable may be used for connecting field current circuit to the digital outputs.
  - On the module side, the shielding must be connected to the cable shield rail (use SK 20 shield connection terminal block or similar).
  - When using stranded wires, HIMA recommends fastening ferrules to the wire ends. The terminals must be suitable for fastening the cross-sections of the cables in use.
- A redundant output wiring is possible using the X-FTA 002 02, Chapter 4.4.

#### 4.1.1 Wiring Outputs not in Use

Outputs that are not being used may stay open and need not be terminated. To prevent short-circuits and sparks in the field zone, never connect a wire to a connector board if it is open on the field side.

## 4.2 Mounting and Removing the Module

When replacing an existing module or mounting a new one, follow the instructions given in this chapter.

When removing the module, the connector board remains in the HIMax base plate. This saves additional wiring effort since all field terminals are connected via the connector board of the module.

### 4.2.1 Mounting a Connector Board

Tools and utilities

- Screwdriver, slotted 0.8 x 4.0 mm
- Matching connector board

#### To install the connector board

1. Insert the connector board into the guiding rail with the groove facing upwards (see following figure). Fit the groove into the guiding rail pin.
2. Place the connector board on the cable shield rail.
3. Secure the two captive screws to the base plate. First screw in the lower than the upper screw.

#### To remove the connector board

1. Release the captive screws from the base plate.
2. Lift the lower section of the connector board from the cable shield rail.
3. Remove the connector board from the guiding rail.




Figure 9: Inserting the Connector Board




Figure 10: Securing the Connector Board with Captive Screws

## 4.2.2 Mounting and Removing the Module

This chapter describes how to mount and remove the HIMax module. A module can be mounted and removed while the HIMax system is operating.

### NOTICE



**Damage to bus and power sockets due to module jamming!**

**Failure to observe this can damage the controller.**

**Always take care when inserting the module in the base plate.**

#### Tools and utilities


- Screwdriver, slotted 0.8 x 4.0 mm
- Screwdriver, slotted 1.2 x 8.0 mm

#### Installation

1. Open the cover plate on the fan rack:
  - Move the locks to the *open* position.
  - Lift the cover plate and insert into the fan rack
2. Insert the top of the module into the hook-in rail, see **1**.
3. Swivel the lower edge of the module towards the base plate and apply light pressure to snap it into place, see **2**.
4. Tighten the screws, see **3**.
5. Pull the cover plate out of the fan rack and close it.
6. Lock the cover plate.

#### Removal

1. Open the cover plate on the fan rack:
  - Move the locks to the *open* position.
  - Lift the cover plate and insert into the fan rack
2. Release the screw **3**.
3. Swivel the lower edge of the module away from the base plate. Lift and apply light pressure to remove the module from the hook-in rail, see **2** and **1**.
4. Pull the cover plate out of the fan rack and close it.
5. Lock the cover plate.



**1** Inserting and Removing a Module

**2** Swiveling a Module in and out

**3** Securing and Releasing a Module

Figure 11: Mounting and Removing a Module

**i**

If the HIMax system is operating, do not open the cover plate of the fan rack for more than a few minutes (< 10 min) since this affects the forced cooling.

### 4.3 Configuring the Module in SILworX

The module is configured in the Hardware Editor of the SILworX programming tool.

Observe the following points when configuring the module:

- To diagnose the module and channels, both the statuses and the channel value can be evaluated within the user program. For more information on the system parameters, refer to the tables starting with Chapter 4.3.1.
- If a redundancy group is created, its configuration is defined in the tabs. The tabs specific to the redundancy group differ from those of the individual modules, see the following tables.

To evaluate the statuses from within the user program, system parameters are assigned global variables. Perform this step in the Hardware Editor using the module's detail view.

The following tables present the statuses and parameters for the module in the same order given in the SILworX Hardware Editor.

---

**TIP** To convert hexadecimal values to bit strings a scientific calculator such as the Windows<sup>®</sup> calculator with the corresponding view can be used.

---

## 4.3.1 Tab: Module

The **Module** tab contains the statuses and parameters for the module.

Name	R/W	Description																			
Enter these statuses and parameters directly in the Hardware Editor.																					
Name	W	Module name																			
Spare Module	W	Activated: The module missing in the redundancy group is not considered as a fault. Deactivated: The module missing in the redundancy group is considered as a fault. Default setting: Deactivated <b>It is only displayed in the redundancy group tab!</b>																			
Noise Blanking	W	Noise blanking performed by processor module allowed (activated/deactivated). Default setting: Activated Status acknowledgments are suppressed until the safety time. The user program retains its last valid process value.																			
Name	Data Type	R/W	Description																		
The following statuses and parameters can be assigned global variables and used in the user program.																					
Module OK	BOOL	R	TRUE: Mono operation: No module faults. Redundant operation: At least one of the redundant modules is faultless (OR logic).  FALSE: Module fault Channel fault (no external faults) The module is not plugged in.  Observe the <i>Module Status</i> parameter!																		
Module Status	DWORD	R	Status of the module <table border="1"> <thead> <tr> <th>Coding</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0x00000001</td> <td>Module fault <sup>1)</sup></td> </tr> <tr> <td>0x00000002</td> <td>Temperature threshold 1 exceeded</td> </tr> <tr> <td>0x00000004</td> <td>Temperature threshold 2 exceeded</td> </tr> <tr> <td>0x00000008</td> <td>Incorrect temperature value</td> </tr> <tr> <td>0x00000010</td> <td>Voltage L1+ is defective</td> </tr> <tr> <td>0x00000020</td> <td>Voltage L2+ is defective</td> </tr> <tr> <td>0x00000040</td> <td>Internal voltage is defective</td> </tr> <tr> <td>0x80000000</td> <td>No connection to the module <sup>1)</sup></td> </tr> </tbody> </table> <p><sup>1)</sup> These faults affect the <i>Module OK</i> status and need not be separately evaluated in the user program.</p>	Coding	Description	0x00000001	Module fault <sup>1)</sup>	0x00000002	Temperature threshold 1 exceeded	0x00000004	Temperature threshold 2 exceeded	0x00000008	Incorrect temperature value	0x00000010	Voltage L1+ is defective	0x00000020	Voltage L2+ is defective	0x00000040	Internal voltage is defective	0x80000000	No connection to the module <sup>1)</sup>
Coding	Description																				
0x00000001	Module fault <sup>1)</sup>																				
0x00000002	Temperature threshold 1 exceeded																				
0x00000004	Temperature threshold 2 exceeded																				
0x00000008	Incorrect temperature value																				
0x00000010	Voltage L1+ is defective																				
0x00000020	Voltage L2+ is defective																				
0x00000040	Internal voltage is defective																				
0x80000000	No connection to the module <sup>1)</sup>																				
Timestamp [µs]	DWORD	R	Microsecond fraction of the timestamp. Point in time at which the digital outputs were measured.																		
Timestamp [s]	DWORD	R	Second fraction of the timestamp. Point in time at which the digital outputs were measured.																		

Table 16: Module Tab in the Hardware Editor

## 4.3.2 Tab: I/O Submodule DO32\_51

The **I/O Submodule DO32 51** tab contains the following system parameters.

Name		R/W	Description
Enter these statuses and parameters directly in the Hardware Editor.			
Name		W	Module name, it cannot be modified.
Name	Data Type	R/W	Description
The following statuses and parameters can be assigned global variables and used in the user program.			
Background Test Error	BOOL	R	TRUE: Background test is faulty FALSE: Background test is free of faults
Diagnostic Request	DINT	W	To request a diagnostic value, the appropriate ID must be sent to the module using the parameter <i>Diagnostic Request</i> (refer to Chapter 4.3.5 for further details).
Diagnostic Response	DINT	R	As soon as <i>Diagnostic Response</i> returns the ID of <i>Diagnostic Request</i> (see 4.3.5 for coding details), <i>Diagnostic Status</i> contains the diagnostic value requested.
Diagnostic Status	DWORD	R	Requested diagnostic value in accordance with <i>Diagnostic Response</i> . The IDs of <i>Diagnostic Request</i> and <i>Diagnostic Response</i> can be evaluated in the user program. <i>Diagnostic Status</i> only contains the requested diagnostic value when both <i>Diagnostic Request</i> and <i>Diagnostic Response</i> have the same ID.
Restart on Error	BOOL	W	Using the parameter <i>Restart on Error</i> , each I/O module that has switched off permanently due to faults can be forced to re-adopt the RUN state. To do this, set the <i>Restart on Error</i> parameter FALSE to TRUE. The I/O module performs a complete self-test and only enters the RUN state if no faults are detected. Default setting: FALSE
Submodule OK	BOOL	R	TRUE: No submodule fault No channel faults FALSE: Submodule fault Channel fault (external faults included)
Submodule Status	DWORD	R	Bit-coded submodule status (see 4.3.4 for coding details)

Table 17: Tab: I/O Submodule DO32\_51 in the Hardware Editor

### 4.3.3 Tab: I/O Submodule DO32\_51: Channels

The **I/O Submodule DO32\_51: Channels** tab contains the following parameters and statuses for each digital output.

Global variables can be assigned to the statuses and parameters with -> and used in the user program. The value without -> must be directly entered.

Name	Data Type	R/W	Description
Channel no.	---	R	Channel number, defined by default
Channel Value [BOOL] ->	BOOL	R	Binary value in accordance with the switching level LOW (dig) and HIGH (dig). TRUE: Channel energized FALSE: Channel de-energized
-> Channel OK	BOOL	R	TRUE: Faultless channel The channel value is valid FALSE: Faulty channel The channel is de-energized
Redund.	BOOL	W	Requirement: A redundant module must exist. Activated: Activate the channel redundancy for this channel Deactivated: Deactivate the channel redundancy for this channel Default setting: Deactivated

Table 18: Tab: I/O Submodule DO32\_51: Channels in the Hardware Editor

### 4.3.4 Submodule Status [DWORD]

Coding of the variable **Submodule Status**.

Coding	Description
0x00000001	Fault in hardware unit (submodule)
0x00000004	Faults detected while configuring the hardware
0x00000040	Overload, module shutdown
0x04000000	Voltage monitoring of L1+ LOW voltage defective
0x10000000	Voltage monitoring of L2+ LOW voltage defective
0x20000000	Voltage monitoring of AGND voltage defective

Table 19: Submodule Status [DWORD]

## 4.3.5 Diagnostic-Status [DWORD]

Coding of the variable **Diagnostic-Status**.

ID	Description								
0	Diagnostic values (100...1032) are indicated consecutively.								
100	Bit-coded temperature status 0 = normal Bit0 = 1 : Temperature threshold 1 has been exceeded Bit1 = 1 : Temperature threshold 2 has been exceeded Bit2 = 1 : Fault in temperature measurement								
101	Measured temperature (10 000 digits/ °C)								
200	Bit-coded voltage status 0 = normal Bit0 = 1 : L1+ (24 V) is faulty Bit1 = 1 : L2+ (24 V) is faulty								
201	Not used!								
202									
203									
300	Comparator 24 V undervoltage (BOOL)								
1001...1032	Status of the channels 1...32 <table border="1" data-bbox="501 891 1382 1041"> <thead> <tr> <th>Coding</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0x0001</td> <td>Fault occurred in hardware unit (submodule).</td> </tr> <tr> <td>0x0002</td> <td>Channel fault due to internal fault</td> </tr> <tr> <td>0x0004</td> <td>Overload, channel shutdown</td> </tr> </tbody> </table>	Coding	Description	0x0001	Fault occurred in hardware unit (submodule).	0x0002	Channel fault due to internal fault	0x0004	Overload, channel shutdown
Coding	Description								
0x0001	Fault occurred in hardware unit (submodule).								
0x0002	Channel fault due to internal fault								
0x0004	Overload, channel shutdown								

Table 20: Diagnostic Information [DWORD]

### 4.4 Connection Variants


This chapter describes the technically proper wiring of the module. The connection variants specified here are permitted.

The outputs are wired via connector boards.

The following points must be taken into account when connecting the loads to the outputs:

- A protective circuit (such as free-wheeling diode or varistor) is required when connecting inductive loads.
- Unshielded, twisted pairs of cables may be connected.
- The ground wires of the outputs may not be interconnected.


#### 4.4.1 1-Pole Wiring of Actuators



**1** Actuators

Figure 12: 1-Pole Wiring of Amplifiers and Actuators

#### 4.4.2 2-Pole Wiring of Actuators




**1** Actuators

Figure 13: 2-Pole Wiring of Actuators

### 4.4.3 Wiring Actuators to Redundant Modules

Actuators can be wired to redundant modules using two mono connector boards with screw terminals (X-CB 009 51) as specified in Figure 14.



**1** Actuators


Figure 14: Redundant Wiring of Actuators

**i**

The wiring described above is only allowed if both channels have identical channel numbers.

### 4.4.4 Wiring Inductive Loads

When connecting inductive loads, a protective circuit (such as free-wheeling diode or varistor) must be connected in parallel to the load.



**1** Inductive Load with Protective Circuits

Figure 15: Wiring Inductive Loads

### 4.4.5 Wiring Actuators via Field Termination Assembly

Actuators are connected via the X-FTA 002 01 as described in Figure 16. For further information, refer to the X-FTA 002 01 Manual (HI 801 116 E).




Figure 16: Wiring Actuators via Field Termination Assembly

## 5 Operation

The module runs within a HIMax base plate and does not require any specific monitoring.

### 5.1 Handling

Direct handling of the module is not foreseen.

The module is operated from within the PADT, e.g., for forcing the outputs. For more details, refer to the SILworX documentation.

### 5.2 Diagnosis

LEDs on the front side of the module indicate the module state, see Chapter 3.4.2.

The diagnostic history of the module can also be read using SILworX. Chapter 4.3.4 and Chapter 4.3.5 describe the most important module-specific diagnostic messages.

---

**i**

If a module is plugged in to a base plate, it generates diagnostic messages during its initialization phase indicating faults such as incorrect voltage values.

These messages only indicate a module fault if they occur after the system starts operation.

---

## 6 Maintenance

Defective modules must be replaced with a faultless module of the same type or with an approved replacement model.

Only the manufacturer is authorized to repair the module.

When replacing modules, observe the instructions specified in the System Manual (HI 801 001 E).

### 6.1 Maintenance Measures

#### 6.1.1 Loading the Operating System

HIMA is continuously improving the operating system of the module. HIMA recommends to use system downtimes to load the current version of the operating system into the module.

For detailed instructions on how to load the operating system, see the system manual and the online help. The module must be in STOP to be able to load an operating system.

---

**i**

The current version of the module in use is displayed in the SILworX Control Panel! The type label specifies the version when the module is delivered, see Chapter 3.3.

---

## 7 Decommissioning

To decommission the module, remove it from the base plate. For more information, see *Mounting and Removing the Module*.

## 8 Transport

To avoid mechanical damage, HIMax components must be transported in packaging.

Always store HIMax components in their original product packaging. This packaging also provides protection against electrostatic discharge. Note that the product packaging alone is not suitable for transport.

## 9 Disposal

Industrial customers are responsible for correctly disposing of decommissioned HIMax hardware. Upon request, a disposal agreement can be arranged with HIMA.

All materials must be disposed of in an ecologically sound manner.

## Appendix

### Glossary

Term	Description
ARP	Address Resolution Protocol: Network protocol for assigning the network addresses to hardware addresses
AI	Analog Input
Connector Board	Connector board for the HIMax module
COM	Communication module
CRC	Cyclic Redundancy Check
DI	Digital Input
DO	Digital Output
EMC	Electromagnetic Compatibility
EN	European Norm
ESD	ElectroStatic Discharge
FB	Fieldbus
FBD	Function Block Diagram
FTT	Fault Tolerance Time
ICMP	Internet Control Message Protocol: Network protocol for status or error messages
IEC	International Electrotechnical Commission
MAC address	Hardware address of one network connection (Media Access Control)
PADT	Programming And Debugging Tool (in accordance with IEC 61131-3), PC with SILworX
PE	Protective Earth
PELV	Protective Extra Low Voltage
PES	Programmable Electronic System
PFD	Probability of Failure on Demand, probability of failure on demand of a safety function
PFH	Probability of Failure per Hour, probability of a dangerous failure per hour
R	Read
Rack ID	Base plate identification (number)
Non-reactive	Supposing that two input circuits are connected to the same source (e.g., a transmitter). An input circuit is termed "non-reactive" if it does not distort the signals of the other input circuit.
R/W	Read/Write
SB	System Bus (Module)
SELV	Safety Extra Low Voltage
SFF	Safe Failure Fraction, portion of safely manageable faults
SIL	Safety Integrity Level (in accordance with IEC 61508)
SILworX	Programming tool for HIMax
SNTP	Simple Network Time Protocol (RFC 1769)
SRS	System.Rack.Slot addressing of a module
SW	Software
TMO	TiMeOut
TMR	Triple Module Redundancy
W	Write
$r_p$	Peak value of a total AC component
Watchdog (WD)	Time monitoring for modules or programs. If the watchdog time is exceeded, the module or program enters the ERROR STOP state.
WDT	WatchDog Time

**Index of Figures**

<b>Figure 1: Sample Type Label</b>	<b>11</b>
<b>Figure 2: Block Diagram</b>	<b>13</b>
<b>Figure 3: Indicators</b>	<b>14</b>
<b>Figure 4: Views</b>	<b>17</b>
<b>Figure 5: Coding Example</b>	<b>20</b>
<b>Figure 6: Connector Board with Screw Terminals</b>	<b>21</b>
<b>Figure 7: Connector Board with Cable Plug</b>	<b>24</b>
<b>Figure 8: X-CA 006 01 n</b>	<b>26</b>
<b>Figure 9: Inserting the Connector Board</b>	<b>29</b>
<b>Figure 10: Securing the Connector Board with Captive Screws</b>	<b>30</b>
<b>Figure 11: Mounting and Removing a Module</b>	<b>32</b>
<b>Figure 12: 1-Pole Wiring of Amplifiers and Actuators</b>	<b>38</b>
<b>Figure 13: 2-Pole Wiring of Actuators</b>	<b>38</b>
<b>Figure 14: Redundant Wiring of Actuators</b>	<b>39</b>
<b>Figure 15: Wiring Inductive Loads</b>	<b>39</b>
<b>Figure 16: Wiring Actuators via Field Termination Assembly</b>	<b>40</b>

**Index of Tables**

<b>Table 1:</b>	<b>Additional Relevant Manuals</b>	<b>5</b>
<b>Table 2:</b>	<b>Environmental Requirements</b>	<b>8</b>
<b>Table 3:</b>	<b>Blinking Frequencies of LEDs</b>	<b>15</b>
<b>Table 4:</b>	<b>Module Status Indicators</b>	<b>15</b>
<b>Table 5:</b>	<b>System Bus Indicators</b>	<b>16</b>
<b>Table 6:</b>	<b>I/O Indicators LEDs</b>	<b>16</b>
<b>Table 7:</b>	<b>Product Data</b>	<b>17</b>
<b>Table 8:</b>	<b>Specifications for the Digital Outputs</b>	<b>18</b>
<b>Table 9:</b>	<b>Available Connector Boards</b>	<b>19</b>
<b>Table 10:</b>	<b>Position of Coding Wedges</b>	<b>20</b>
<b>Table 11:</b>	<b>Terminal Assignment for Connector Boards with Screw Terminals</b>	<b>22</b>
<b>Table 12:</b>	<b>Cable Plug Properties</b>	<b>23</b>
<b>Table 13:</b>	<b>Pin Assignment for the System Cable Plug</b>	<b>25</b>
<b>Table 14:</b>	<b>Cable Data</b>	<b>26</b>
<b>Table 15:</b>	<b>Available System Cables</b>	<b>26</b>
<b>Table 16:</b>	<b>Module Tab in the Hardware Editor</b>	<b>34</b>
<b>Table 17:</b>	<b>Tab: I/O Submodule DO32_51 in the Hardware Editor</b>	<b>35</b>
<b>Table 18:</b>	<b>Tab: I/O Submodule DO32_51: Channels in the Hardware Editor</b>	<b>36</b>
<b>Table 19:</b>	<b>Submodule Status [DWORD]</b>	<b>36</b>
<b>Table 20:</b>	<b>Diagnostic Information [DWORD]</b>	<b>37</b>

**Index**

block diagram.....	13	diagnosis	
connection variant.....	38	I/O indicators.....	16
connector board		system bus indicators .....	16
with cable plug.....	24	module status indicators.....	15
with screw terminals .....	21	safety function .....	10
connector boards .....	19	specifications.....	17

HI 801 183 E

© 2012 HIMA Paul Hildebrandt GmbH + Co KG  
HIMax and SILworX are registered trademark of:  
HIMA Paul Hildebrandt GmbH + Co KG

Albert-Bassermann-Str. 28  
68782 Brühl, Germany  
Phone: +49 6202 709-0  
Fax +49 6202 709-107  
HIMax-info@hima.com  
www.hima.com



SAFETY  
NONSTOP