



 PRODUCT-DETAILS

3ADT313900R1501

SDCS-CON-4-COAT-ROHS; SDCS-CON-4 COAT-ROHS CONTROL BOARD



General Information

Product ID	3ADT313900R1501
ABB Type Designation	SDCS-CON-4-COAT-ROHS
Catalog Description	SDCS-CON-4-COAT-ROHS; SDCS-CON-4 COAT-ROHS CONTROL BOARD

Additional Information

ABB Type Designation	SDCS-CON-4-COAT-ROHS
CN8	85371098
Core Credit	0.00
Country of Origin	China (CN) Hong Kong Special Administrative Region of China
Customs Tariff Number	85371098
Frame Size	Spare_Parts
Gross Weight	0.399 kg
Invoice Description	SDCS-CON-4 COAT-ROHS CONTROL BOARD
Made To Order	No
Minimum Order Quantity	1 piece
Order Multiple	1 piece

Package Level 1 Gross Weight	0.399 kg
Package Level 1 Units	1 piece
Part Type	New
Product Name	SDCS-CON-4 COAT-ROHS CONTROL BO
Product Net Weight	0.52 kg
Product Type	Spare_Parts
Quote Only	No
Replaced Product ID (OLD)	3ADT313900R1001
Selling Unit of Measure	piece
Stocked At (Warehouses)	Finland Menden, Germany New Berlin, Wisconsin, United States Beijing, China Singapore, Singapore Tokyo, Japan Finland Bangalore, India
Technical Information	Control board deliveries include always the latest firmware. Current version is 80x3.70. Please pay attention on the compatibilities described in the folder PICTURE
WEEE Category	Product Not in WEEE Scope

Where Used (as a spare part for "Products")

Identifier	Description	Quantity	Unit Of Measure
DCS800-S01-0020-04	No Description Available	1	piece
DCS800-S01-0020-05	No Description Available	1	piece
DCS800-S01-0045-04	No Description Available	1	piece
DCS800-S01-0045-05	No Description Available	1	piece
DCS800-S01-0065-04	No Description Available	1	piece
DCS800-S01-0065-05	No Description Available	1	piece
DCS800-S01-0090-04	No Description Available	1	piece
DCS800-S01-0090-05	No Description Available	1	piece
DCS800-S01-0125-04	No Description Available	1	piece
DCS800-S01-0125-05	No Description Available	1	piece
DCS800-S01-0180-04	No Description Available	1	piece
DCS800-S01-0180-05	No Description Available	1	piece
DCS800-S01-0230-04	No Description Available	1	piece
DCS800-S01-0230-05	No Description Available	1	piece
DCS800-S01-0290-06	No Description Available	1	piece
DCS800-S01-0315-04	No Description Available	1	piece
DCS800-S01-0315-05	No Description Available	1	piece
DCS800-S01-0405-04	No Description Available	1	piece
DCS800-S01-0405-05	No Description Available	1	piece
DCS800-S01-0470-04	No Description Available	1	piece
DCS800-S01-0470-05	No Description Available	1	piece
DCS800-S01-0590-06	No Description Available	1	piece
DCS800-S01-0610-04	No Description Available	1	piece

DCS800-S01-0610-05	No Description Available	1	piece
DCS800-S01-0740-04	No Description Available	1	piece
DCS800-S01-0740-05	No Description Available	1	piece
DCS800-S01-0900-04	No Description Available	1	piece
DCS800-S01-0900-05	No Description Available	1	piece
DCS800-S01-0900-06	No Description Available	1	piece
DCS800-S01-0900-07	No Description Available	1	piece
DCS800-S01-1200-04	No Description Available	1	piece
DCS800-S01-1200-05	No Description Available	1	piece
DCS800-S01-1500-04	No Description Available	1	piece
DCS800-S01-1500-05	No Description Available	1	piece
DCS800-S01-1500-06	No Description Available	1	piece
DCS800-S01-1500-07	No Description Available	1	piece
DCS800-S01-1900-08	No Description Available	1	piece
DCS800-S01-2000-04	No Description Available	1	piece
DCS800-S01-2000-05	No Description Available	1	piece
DCS800-S01-2000-06	No Description Available	1	piece
DCS800-S01-2000-07	No Description Available	1	piece
DCS800-S01-2050-05	No Description Available	1	piece
DCS800-S01-2050-06	No Description Available	1	piece
DCS800-S01-2050-07	No Description Available	1	piece
DCS800-S01-2500-04	No Description Available	1	piece
DCS800-S01-2500-05	No Description Available	1	piece
DCS800-S01-2500-06	No Description Available	1	piece
DCS800-S01-2500-07	No Description Available	1	piece
DCS800-S01-2500-08	No Description Available	1	piece
DCS800-S01-3000-04	No Description Available	1	piece
DCS800-S01-3000-05	No Description Available	1	piece
DCS800-S01-3000-06	No Description Available	1	piece
DCS800-S01-3000-07	No Description Available	1	piece
DCS800-S01-3000-08	No Description Available	1	piece
DCS800-S02-0025-04	No Description Available	1	piece
DCS800-S02-0025-05	No Description Available	1	piece
DCS800-S02-0050-04	No Description Available	1	piece
DCS800-S02-0050-05	No Description Available	1	piece
DCS800-S02-0075-04	No Description Available	1	piece
DCS800-S02-0075-05	No Description Available	1	piece
DCS800-S02-0100-04	No Description Available	1	piece
DCS800-S02-0100-05	No Description Available	1	piece
DCS800-S02-0140-04	No Description Available	1	piece
DCS800-S02-0140-05	No Description Available	1	piece
DCS800-S02-0200-04	No Description Available	1	piece
DCS800-S02-0200-05	No Description Available	1	piece
DCS800-S02-0260-04	No Description Available	1	piece
DCS800-S02-0260-05	No Description Available	1	piece
DCS800-S02-0320-06	No Description Available	1	piece
DCS800-S02-0350-04	No Description Available	1	piece
DCS800-S02-0350-05	No Description Available	1	piece
DCS800-S02-0450-04	No Description Available	1	piece
DCS800-S02-0450-05	No Description Available	1	piece
DCS800-S02-0520-04	No Description Available	1	piece
DCS800-S02-0520-05	No Description Available	1	piece
DCS800-S02-0650-06	No Description Available	1	piece
DCS800-S02-0680-04	No Description Available	1	piece

DCS800-S02-0680-05	No Description Available	1	piece
DCS800-S02-0820-04	No Description Available	1	piece
DCS800-S02-0820-05	No Description Available	1	piece
DCS800-S02-1000-04	No Description Available	1	piece
DCS800-S02-1000-05	No Description Available	1	piece
DCS800-S02-0900-06	No Description Available	1	piece
DCS800-S02-0900-07	No Description Available	1	piece
DCS800-S02-1200-04	No Description Available	1	piece
DCS800-S02-1200-05	No Description Available	1	piece
DCS800-S02-1500-04	No Description Available	1	piece
DCS800-S02-1500-05	No Description Available	1	piece
DCS800-S02-1500-06	No Description Available	1	piece
DCS800-S02-1500-07	No Description Available	1	piece
DCS800-S02-1900-08	No Description Available	1	piece
DCS800-S02-2000-04	No Description Available	1	piece
DCS800-S02-2000-05	No Description Available	1	piece
DCS800-S02-2050-05	No Description Available	1	piece
DCS800-S02-2050-06	No Description Available	1	piece
DCS800-S02-2050-07	No Description Available	1	piece
DCS800-S02-2500-04	No Description Available	1	piece
DCS800-S02-2500-05	No Description Available	1	piece
DCS800-S02-2500-06	No Description Available	1	piece
DCS800-S02-2500-07	No Description Available	1	piece
DCS800-S02-2500-08	No Description Available	1	piece
DCS800-S02-3000-04	No Description Available	1	piece
DCS800-S02-3000-05	No Description Available	1	piece
DCS800-S02-3000-06	No Description Available	1	piece
DCS800-S02-3000-07	No Description Available	1	piece
DCS800-S02-3000-08	No Description Available	1	piece
DCS800-S01-2050-10R	No Description Available	1	piece
DCS800-S01-2600-10R	No Description Available	1	piece
DCS800-S01-3300-04R	No Description Available	1	piece
DCS800-S01-3300-05R	No Description Available	1	piece
DCS800-S01-3300-06R	No Description Available	1	piece
DCS800-S01-3300-07R	No Description Available	1	piece
DCS800-S01-3300-08R	No Description Available	1	piece
DCS800-S01-3300-10R	No Description Available	1	piece
DCS800-S01-4000-04R	No Description Available	1	piece
DCS800-S01-4000-05R	No Description Available	1	piece
DCS800-S01-4000-06R	No Description Available	1	piece
DCS800-S01-4000-07R	No Description Available	1	piece
DCS800-S01-4000-08R	No Description Available	1	piece
DCS800-S01-4000-10R	No Description Available	1	piece
DCS800-S01-4800-06R	No Description Available	1	piece
DCS800-S01-4800-07R	No Description Available	1	piece
DCS800-S01-4800-08R	No Description Available	1	piece
DCS800-S01-5200-04R	No Description Available	1	piece
DCS800-S01-5200-05R	No Description Available	1	piece
DCS800-S02-2050-10R	No Description Available	1	piece
DCS800-S02-2600-10R	No Description Available	1	piece
DCS800-S02-3300-04R	No Description Available	1	piece
DCS800-S02-3300-05R	No Description Available	1	piece
DCS800-S02-3300-06R	No Description Available	1	piece
DCS800-S02-3300-07R	No Description Available	1	piece

DCS800-S02-3300-08R	No Description Available	1	piece
DCS800-S02-3300-10R	No Description Available	1	piece
DCS800-S02-4000-04R	No Description Available	1	piece
DCS800-S02-4000-05R	No Description Available	1	piece
DCS800-S02-4000-06R	No Description Available	1	piece
DCS800-S02-4000-07R	No Description Available	1	piece
DCS800-S02-4000-08R	No Description Available	1	piece
DCS800-S02-4000-10R	No Description Available	1	piece
DCS800-S02-4800-06R	No Description Available	1	piece
DCS800-S02-4800-07R	No Description Available	1	piece
DCS800-S02-4800-08R	No Description Available	1	piece
DCS800-S02-5200-04R	No Description Available	1	piece
DCS800-S02-5200-05R	No Description Available	1	piece
DCS800-S01-2050-10L	No Description Available	1	piece
DCS800-S01-2600-10L	No Description Available	1	piece
DCS800-S01-3300-04L	No Description Available	1	piece
DCS800-S01-3300-05L	No Description Available	1	piece
DCS800-S01-3300-06L	No Description Available	1	piece
DCS800-S01-3300-07L	No Description Available	1	piece
DCS800-S01-3300-08L	No Description Available	1	piece
DCS800-S01-3300-10L	No Description Available	1	piece
DCS800-S01-4000-04L	No Description Available	1	piece
DCS800-S01-4000-05L	No Description Available	1	piece
DCS800-S01-4000-06L	No Description Available	1	piece
DCS800-S01-4000-07L	No Description Available	1	piece
DCS800-S01-4000-08L	No Description Available	1	piece
DCS800-S01-4000-10L	No Description Available	1	piece
DCS800-S01-4800-06L	No Description Available	1	piece
DCS800-S01-4800-07L	No Description Available	1	piece
DCS800-S01-4800-08L	No Description Available	1	piece
DCS800-S01-5200-04L	No Description Available	1	piece
DCS800-S01-5200-05L	No Description Available	1	piece
DCS800-S02-2050-10L	No Description Available	1	piece
DCS800-S02-2600-10L	No Description Available	1	piece
DCS800-S02-3300-04L	No Description Available	1	piece
DCS800-S02-3300-05L	No Description Available	1	piece
DCS800-S02-3300-06L	No Description Available	1	piece
DCS800-S02-3300-07L	No Description Available	1	piece
DCS800-S02-3300-08L	No Description Available	1	piece
DCS800-S02-3300-10L	No Description Available	1	piece
DCS800-S02-4000-04L	No Description Available	1	piece
DCS800-S02-4000-05L	No Description Available	1	piece
DCS800-S02-4000-06L	No Description Available	1	piece
DCS800-S02-4000-07L	No Description Available	1	piece
DCS800-S02-4000-08L	No Description Available	1	piece
DCS800-S02-4000-10L	No Description Available	1	piece
DCS800-S02-4800-06L	No Description Available	1	piece
DCS800-S02-4800-07L	No Description Available	1	piece
DCS800-S02-4800-08L	No Description Available	1	piece
DCS800-S02-5200-04L	No Description Available	1	piece
DCS800-S02-5200-05L	No Description Available	1	piece
DCS800-S01-0900-06a	No Description Available	1	piece
DCS800-S01-0900-06-b	No Description Available	1	piece
DCS800-S01-0900-07a	No Description Available	1	piece

DCS800-S01-0900-07-b	No Description Available	1	piece
DCS800-S01-1190-04	No Description Available	1	piece
DCS800-S01-1190-05	No Description Available	1	piece
DCS800-S01-1200-04a	No Description Available	1	piece
DCS800-S01-1200-04-b	No Description Available	1	piece
DCS800-S01-1200-05a	No Description Available	1	piece
DCS800-S01-1200-05-b	No Description Available	1	piece
DCS800-S01-1500-04-b	No Description Available	1	piece
DCS800-S01-1500-05-b	No Description Available	1	piece
DCS800-S01-1500-06-b	No Description Available	1	piece
DCS800-S01-1500-07-b	No Description Available	1	piece
DCS800-S01-1900-08a	No Description Available	1	piece
DCS800-S01-1900-08-b	No Description Available	1	piece
DCS800-S01-2000-04-b	No Description Available	1	piece
DCS800-S01-2000-05-b	No Description Available	1	piece
DCS800-S01-2000-06-b	No Description Available	1	piece
DCS800-S01-2000-07-b	No Description Available	1	piece
DCS800-S01-2050-05a	No Description Available	1	piece
DCS800-S01-2050-05-b	No Description Available	1	piece
DCS800-S01-2050-06a	No Description Available	1	piece
DCS800-S01-2050-06-b	No Description Available	1	piece
DCS800-S01-2050-07a	No Description Available	1	piece
DCS800-S01-2050-07-b	No Description Available	1	piece
DCS800-S01-2050-10-b	No Description Available	1	piece
DCS800-S01-2500-04-b	No Description Available	1	piece
DCS800-S01-2500-05-b	No Description Available	1	piece
DCS800-S01-2500-06-b	No Description Available	1	piece
DCS800-S01-2500-07-b	No Description Available	1	piece
DCS800-S01-2500-08-b	No Description Available	1	piece
DCS800-S01-2600-10-b	No Description Available	1	piece
DCS800-S01-3000-04-b	No Description Available	1	piece
DCS800-S01-3000-05-b	No Description Available	1	piece
DCS800-S01-3000-06-b	No Description Available	1	piece
DCS800-S01-3000-07-b	No Description Available	1	piece
DCS800-S01-3000-08-b	No Description Available	1	piece
DCS800-S01-3300-04-b	No Description Available	1	piece
DCS800-S01-3300-05-b	No Description Available	1	piece
DCS800-S01-3300-06-b	No Description Available	1	piece
DCS800-S01-3300-07-b	No Description Available	1	piece
DCS800-S01-3300-08-b	No Description Available	1	piece
DCS800-S01-3300-10-b	No Description Available	1	piece
DCS800-S01-4000-04-b	No Description Available	1	piece
DCS800-S01-4000-05-b	No Description Available	1	piece
DCS800-S01-4000-06-b	No Description Available	1	piece
DCS800-S01-4000-07-b	No Description Available	1	piece
DCS800-S01-4000-08-b	No Description Available	1	piece
DCS800-S01-4000-10-b	No Description Available	1	piece
DCS800-S01-4800-06-b	No Description Available	1	piece
DCS800-S01-4800-07-b	No Description Available	1	piece
DCS800-S01-4800-08-b	No Description Available	1	piece
DCS800-S01-5200-04-b	No Description Available	1	piece
DCS800-S01-5200-05-b	No Description Available	1	piece
DCS800-S02-0650-07	No Description Available	1	piece
DCS800-S02-0900-06a	No Description Available	1	piece

DCS800-S02-0900-06-b	No Description Available	1	piece
DCS800-S02-0900-07a	No Description Available	1	piece
DCS800-S02-0900-07-b	No Description Available	1	piece
DCS800-S02-1190-04	No Description Available	1	piece
DCS800-S02-1190-05	No Description Available	1	piece
DCS800-S02-1200-04a	No Description Available	1	piece
DCS800-S02-1200-04-b	No Description Available	1	piece
DCS800-S02-1200-05a	No Description Available	1	piece
DCS800-S02-1200-05-b	No Description Available	1	piece
DCS800-S02-1500-04-b	No Description Available	1	piece
DCS800-S02-1500-05-b	No Description Available	1	piece
DCS800-S02-1500-06-b	No Description Available	1	piece
DCS800-S02-1500-07-b	No Description Available	1	piece
DCS800-S02-1900-08a	No Description Available	1	piece
DCS800-S02-1900-08-b	No Description Available	1	piece
DCS800-S02-2000-04-b	No Description Available	1	piece
DCS800-S02-2000-05-b	No Description Available	1	piece
DCS800-S02-2050-05a	No Description Available	1	piece
DCS800-S02-2050-05-b	No Description Available	1	piece
DCS800-S02-2050-06a	No Description Available	1	piece
DCS800-S02-2050-06-b	No Description Available	1	piece
DCS800-S02-2050-07a	No Description Available	1	piece
DCS800-S02-2050-07-b	No Description Available	1	piece
DCS800-S02-2050-10-b	No Description Available	1	piece
DCS800-S02-2500-04-b	No Description Available	1	piece
DCS800-S02-2500-05-b	No Description Available	1	piece
DCS800-S02-2500-06-b	No Description Available	1	piece
DCS800-S02-2500-07-b	No Description Available	1	piece
DCS800-S02-2500-08-b	No Description Available	1	piece
DCS800-S02-2600-10-b	No Description Available	1	piece
DCS800-S02-3000-04-b	No Description Available	1	piece
DCS800-S02-3000-05-b	No Description Available	1	piece
DCS800-S02-3000-06-b	No Description Available	1	piece
DCS800-S02-3000-07-b	No Description Available	1	piece
DCS800-S02-3000-08-b	No Description Available	1	piece
DCS800-S02-3300-04-b	No Description Available	1	piece
DCS800-S02-3300-05-b	No Description Available	1	piece
DCS800-S02-3300-06-b	No Description Available	1	piece
DCS800-S02-3300-07-b	No Description Available	1	piece
DCS800-S02-3300-08-b	No Description Available	1	piece
DCS800-S02-3300-10-b	No Description Available	1	piece
DCS800-S02-4000-04-b	No Description Available	1	piece
DCS800-S02-4000-05-b	No Description Available	1	piece
DCS800-S02-4000-06-b	No Description Available	1	piece
DCS800-S02-4000-07-b	No Description Available	1	piece
DCS800-S02-4000-08-b	No Description Available	1	piece
DCS800-S02-4000-10-b	No Description Available	1	piece
DCS800-S02-4800-06-b	No Description Available	1	piece
DCS800-S02-4800-07-b	No Description Available	1	piece
DCS800-S02-4800-08-b	No Description Available	1	piece
DCS800-S02-5200-04-b	No Description Available	1	piece
DCS800-S02-5200-05-b	No Description Available	1	piece

Product specific part data

Product	Category	Drive Part Category
DCS800-S01-0020-04	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-0020-05	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-0045-04	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-0045-05	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-0065-04	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-0065-05	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-0090-04	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-0090-05	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-0125-04	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-0125-05	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-0180-04	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-0180-05	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-0230-04	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-0230-05	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-0290-06	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-0315-04	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-0315-05	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-0405-04	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-0405-05	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-0470-04	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-0470-05	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-0590-06	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-0610-04	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-0610-05	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-0740-04	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-0740-05	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-0900-04	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-0900-05	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-0900-06	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-0900-07	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-1200-04	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-1200-05	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-1500-04	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-1500-05	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-1500-06	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-1500-07	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-1900-08	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-2000-04	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-2000-05	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-2000-06	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-2000-07	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-2050-05	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-2050-06	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-2050-07	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-2500-04	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-2500-05	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-2500-06	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-2500-07	DCS800-S	Boards, Control Units, Power Supplies

Product	Category	Drive Part Category
DCS800-S01-2500-08	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-3000-04	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-3000-05	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-3000-06	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-3000-07	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-3000-08	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-0025-04	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-0025-05	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-0050-04	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-0050-05	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-0075-04	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-0075-05	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-0100-04	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-0100-05	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-0140-04	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-0140-05	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-0200-04	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-0200-05	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-0260-04	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-0260-05	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-0320-06	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-0350-04	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-0350-05	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-0450-04	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-0450-05	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-0520-04	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-0520-05	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-0650-06	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-0680-04	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-0680-05	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-0820-04		Boards, Control Units, Power Supplies
DCS800-S02-0820-05	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-1000-04	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-1000-05	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-0900-06	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-0900-07	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-1200-04	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-1200-05	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-1500-04	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-1500-05	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-1500-06	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-1500-07	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-1900-08	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-2000-04	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-2000-05	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-2050-05	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-2050-06	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-2050-07	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-2500-04	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-2500-05	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-2500-06	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-2500-07	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-2500-08	DCS800-S	Boards, Control Units, Power Supplies

Product	Category	Drive Part Category
DCS800-S01-4000-06L	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-4000-07L	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-4000-08L	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-4000-10L	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-4800-06L	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-4800-07L	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-4800-08L	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-5200-04L	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-5200-05L	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-2050-10L		Boards, Control Units, Power Supplies
DCS800-S02-2600-10L	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-3300-04L	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-3300-05L	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-3300-06L	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-3300-07L	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-3300-08L	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-3300-10L	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-4000-04L	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-4000-05L	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-4000-06L	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-4000-07L	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-4000-08L	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-4000-10L	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-4800-06L	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-4800-07L	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-4800-08L	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-5200-04L	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-5200-05L	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-0900-06a	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-0900-06-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-0900-07a	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-0900-07-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-1190-04	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-1190-05	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-1200-04a	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-1200-04-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-1200-05a	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-1200-05-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-1500-04-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-1500-05-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-1500-06-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-1500-07-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-1900-08a	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-1900-08-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-2000-04-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-2000-05-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-2000-06-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-2000-07-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-2050-05a	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-2050-05-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-2050-06a	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-2050-06-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-2050-07a	DCS800-S	Boards, Control Units, Power Supplies

Product	Category	Drive Part Category
DCS800-S01-2050-07-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-2050-10-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-2500-04-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-2500-05-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-2500-06-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-2500-07-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-2500-08-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-2600-10-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-3000-04-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-3000-05-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-3000-06-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-3000-07-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-3000-08-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-3300-04-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-3300-05-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-3300-06-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-3300-07-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-3300-08-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-3300-10-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-4000-04-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-4000-05-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-4000-06-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-4000-07-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-4000-08-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-4000-10-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-4800-06-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-4800-07-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-4800-08-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-5200-04-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S01-5200-05-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-0650-07	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-0900-06a	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-0900-06-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-0900-07a	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-0900-07-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-1190-04	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-1190-05	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-1200-04a	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-1200-04-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-1200-05a	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-1200-05-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-1500-04-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-1500-05-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-1500-06-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-1500-07-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-1900-08a	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-1900-08-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-2000-04-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-2000-05-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-2050-05a	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-2050-05-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-2050-06a	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-2050-06-b	DCS800-S	Boards, Control Units, Power Supplies

Product	Category	Drive Part Category
DCS800-S02-2050-07a	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-2050-07-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-2050-10-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-2500-04-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-2500-05-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-2500-06-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-2500-07-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-2500-08-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-2600-10-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-3000-04-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-3000-05-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-3000-06-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-3000-07-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-3000-08-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-3300-04-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-3300-05-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-3300-06-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-3300-07-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-3300-08-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-3300-10-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-4000-04-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-4000-05-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-4000-06-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-4000-07-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-4000-08-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-4000-10-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-4800-06-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-4800-07-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-4800-08-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-5200-04-b	DCS800-S	Boards, Control Units, Power Supplies
DCS800-S02-5200-05-b	DCS800-S	Boards, Control Units, Power Supplies

Categories

Drives → DC Drives → Industrial Drives → Modules → DCS800-S

Drives → DC Drives → Industrial Drives → Retrofit Solutions → DCS800-R Rebuilt Kit

